


# Exterior Finish

## Key:

- A. Fill in gap from previously removed doors and windows to be flush with exterior surface.
- B. Install new 4" Novabrick or equivalent mortiseless brick to North side extrusions, East and West sides, and South corner.
- C. Install new awning.

## Notes:

1. On all exterior surfaces, remove all Stucco with Asbestos and Lead paint from Exterior walls.
2. Install on all surfaces the new EIFS.
3. Exterior paint color shall match new and existing buildings on the property or as determined by the Project Engineer.

	
Project Name and Address SPD HVAC Upgrades 657A5-08-109	
Project 657A7-07-109	Sheet 3 OF 4
Date 12/08/2008	Scale No Scale